

Connecting Floating Differential Signals

You can connect floating differential signals to the NI 9234.

Figure 2. Connecting Floating Differential Signals to the NI 9234

