



Mount your block on a panel or DIN rail.



Horizontal Mounting



Vertical Mounting

The longer expansion cable (1790-15CMCBL) provides for up to 7 cm (2.76 in.) of space in between blocks.

44155

Wire the Terminal Block

WARNING



If you connect or disconnect wiring while the field-side power is on, an electrical arc can occur. This could cause an explosion in hazardous location installations. Be sure that power is removed or the area is nonhazardous before proceeding.